

Example 6.1 (Textbook 9.3, p.228) The connection to be made in the lap joint is to withstand a service tensile load of 50 kips dead load and 50 kips of live load. Using 1-in. A325-X bolts, determine the number of bolts required for (a) bearing type and (b) slip-critical type connections.