



To turn system ON

- 1) Set TX throttle to min
- 2) Turn TX on
- 3) Plug in battery

To turn system OFF

- 4) Unplug battery
- 5) Turn TX off

Electric RC Airplane Radio Gear Hookup