



Complex exponentials are eigenfunctions of LTI systems.

$$e^{s_0 t} \longrightarrow H(s_0) e^{s_0 t}$$

 $H(s_0)$  can be determined graphically using vectorial analysis.

$$H(s_0) = K \frac{(s_0 - z_0)(s_0 - z_1)(s_0 - z_2)\cdots}{(s_0 - p_0)(s_0 - p_1)(s_0 - p_2)\cdots}$$
solution solut

Response of an LTI system to an eternal cosine is an eternal cosine: same frequency, but scaled and shifted.


$$\cos(\omega_0 t) \longrightarrow H(s) \longrightarrow |H(j\omega_0)| \cos\left(\omega_0 t + \angle H(j\omega_0)\right)$$


#### **Poles and Zeros**


Thinking about systems as collections of poles and zeros is an important design concept.


- simple: just a few numbers characterize entire system
- powerful: complete information about frequency response

Today: poles, zeros, frequency responses, and Bode plots.









# Check Yourself


Compare log-log plots of the frequency-response magnitudes of the following system functions:


$$H_1(s) = \frac{1}{s+1}$$
 and  $H_2(s) = \frac{1}{s+10}$ 

The former can be transformed into the latter by

- 1. shifting horizontally
- 2. shifting and scaling horizontally
- 3. shifting both horizontally and vertically
- 4. shifting and scaling both horizontally and vertically

5. none of the above







#### Bode Plot


The log of the magnitude is a sum of logs.


$$|H(s_0)| = \left| K \quad \frac{\prod_{q=1}^{Q} (s_0 - z_q)}{\prod_{p=1}^{P} (s_0 - p_p)} \right| = |K| \quad \frac{\prod_{q=1}^{Q} |s_0 - z_q|}{\prod_{p=1}^{P} |s_0 - p_p|}$$
$$\log|H(j\omega)| = \log|K| + \sum_{q=1}^{Q} \log|j\omega - z_q| - \sum_{p=1}^{P} \log|j\omega - p_p|$$


Lecture 10


















Lecture 10




The angle of K can be 0 or  $\pi$  for systems described by linear differential equations with constant, real-valued coefficients.














#### Lecture 10
















Lecture 10






Estimate the "3dB bandwidth" of the peak (assume Q > 3).


Let  $\omega_l$  (or  $\omega_h$ ) represent the lowest (or highest) frequency for which the magnitude is greater than the peak value divided by  $\sqrt{2}$ . The 3dB bandwidth is then  $\omega_h - \omega_l$ .





# Frequency Response of a High-Q System

As  ${\it Q}$  increases, the phase changes more abruptly with  $\omega.$ 



#### Summary

The frequency response of a system can be quickly determined using Bode plots.

Bode plots are constructed from sections that correspond to single poles and single zeros.

Responses for each section simply sum when plotted on logarithmic coordinates.



Estimate change in phase that occurs over the 3dB bandwidth.

$$H(s) = \frac{1}{1 + \frac{1}{Q} \frac{s}{\omega_0} + \left(\frac{s}{\omega_0}\right)^2}$$

$$\frac{s}{\omega_0} \text{ plane} \int \sqrt{1 - \left(\frac{1}{2Q}\right)^2} 0 \int \sqrt{1 - \left(\frac{1}{2Q}\right)^2} \int \sqrt{1 - \left(\frac{1}{2Q}\right)^2}$$