

Lecture 5 - PN Junction and MOS Electrostatics (II)

PN JUNCTION IN THERMAL EQUILIBRIUM

February 22, 2000

Contents:

1. Introduction to pn junction
2. Electrostatics of pn junction in thermal equilibrium
3. The depletion approximation
4. Contact potentials

Reading assignment:

Howe and Sodini, Ch. 3, §§3.3-3.6

Key questions


- What happens if the doping distribution in a semiconductor abruptly changes from n-type to p-type?
- Is there a simple description of the electrostatics of a pn junction?

1. Introduction to pn junction

- pn junction: p-region and n-region in intimate contact
- Why is the p-n junction worth studying?

It is present in virtually every semiconductor device!


Example: CMOS cross section




Understanding p-n junction is essential to understanding transistor operation.

2. Electrostatics of p-n junction in equilibrium

Focus on intrinsic region:




Doping distribution of abrupt p-n junction:



What is the carrier concentration distribution in thermal equilibrium?


First think of two sides separately:



Now bring them together. What happens?


Diffusion of electrons and holes from majority carrier side to minority carrier side until drift balances diffusion.

Resulting carrier profile in thermal equilibrium:



- Far away from metallurgical junction: nothing happens
 - two *quasi-neutral regions*
- Around metallurgical junction: carrier diffusion must cancel drift
 - *space-charge region*

In a linear scale:



Thermal equilibrium: balance between drift and diffusion

$$\begin{array}{c}
 \xrightarrow{J_h^{\text{diff}}} \\
 \xleftarrow{J_h^{\text{drift}}} \\
 \xrightarrow{J_e^{\text{diff}}} \\
 \xleftarrow{J_e^{\text{drift}}}
 \end{array}$$

Can divide semiconductor in three regions:


- two quasi-neutral n- and p-regions (QNR's)
- one space charge region (SCR)

Now, want to know $n_o(x)$, $p_o(x)$, $\rho(x)$, $E(x)$, and $\phi(x)$.

Solve electrostatics using simple, powerful approximation.


3. The depletion approximation

- Assume QNR's perfectly charge neutral
- assume SCR depleted of carriers (*depletion region*)
- transition between SCR and QNR's sharp
(must calculate where to place $-x_{po}$ and x_{no})



- $x < -x_{po}$ $p_o(x) = N_a, \quad n_o(x) = \frac{n_i^2}{N_a}$
- $-x_{po} < x < 0$ $p_o(x), \quad n_o(x) \ll N_a$
- $0 < x < x_{no}$ $n_o(x), \quad p_o(x) \ll N_d$
- $x_{no} < x$ $n_o(x) = N_d, \quad p_o(x) = \frac{n_i^2}{N_d}$

● SPACE CHARGE DENSITY




$$\begin{aligned}
 \rho(x) &= 0 & x < -x_{po} \\
 &= -qN_a & -x_{po} < x < 0 \\
 &= qN_d & 0 < x < x_{no} \\
 &= 0 & x_{no} < x
 \end{aligned}$$

● ELECTRIC FIELD

Integrate Gauss' equation:

$$E(x_1) - E(x_2) = \frac{1}{\epsilon} \int_{x_1}^{x_2} \rho(x) dx$$



$$\bullet \quad x < -x_{po} \quad E(x) = 0$$

$$\begin{aligned} \bullet \quad -x_{po} < x < 0 \quad E(x) - E(-x_{po}) &= \frac{1}{\epsilon} \int_{-x_{po}}^x -qN_a dx \\ &= \frac{-qN_a}{\epsilon} x \Big|_{-x_{po}}^x = \frac{-qN_a}{\epsilon} (x + x_{po}) \end{aligned}$$

$$\bullet \quad 0 < x < x_{no} \quad E(x) = \frac{qN_d}{\epsilon} (x - x_{no})$$

$$\bullet \quad x_{no} < x \quad E(x) = 0$$

• ELECTROSTATIC POTENTIAL


(with $\phi = 0$ @ $n_o = p_o = n_i$):

$$\phi = \frac{kT}{q} \ln \frac{n_o}{n_i} \qquad \phi = -\frac{kT}{q} \ln \frac{p_o}{n_i}$$

In QNR's, n_o , p_o known \Rightarrow can determine ϕ :

$$\text{in p-QNR: } p_o = N_a \Rightarrow \phi_p = -\frac{kT}{q} \ln \frac{N_a}{n_i}$$

$$\text{in n-QNR: } n_o = N_d \Rightarrow \phi_n = \frac{kT}{q} \ln \frac{N_d}{n_i}$$






Built-in potential:


$$\phi_B = \phi_n - \phi_p = \frac{kT}{q} \ln \frac{N_a N_d}{n_i^2}$$

General expression: did not use depletion approximation.

To get $\phi(x)$ in between, integrate $E(x)$:

$$\phi(x_1) - \phi(x_2) = - \int_{x_1}^{x_2} E(x) dx$$





- $x < -x_{po}$ $\phi(x) = \phi_p$
- $-x_{po} < x < 0$ $\phi(x) = \phi(-x_{po}) - \int_{-x_{po}}^x \frac{qN_a}{\epsilon}(x + x_{po})dx$
 $= \frac{qN_a}{2\epsilon}(x + x_{po})^2$
- $0 < x < x_{no}$ $\phi(x) = \phi_n - \frac{qN_d}{2\epsilon}(x - x_{no})^2$
- $x_{no} < x$ $\phi(x) = \phi_n$

Almost done...

Still don't know x_{no} and $x_{po} \Rightarrow$ need two more equations

1. Require overall charge neutrality:

$$qN_ax_{po} = qN_dx_{no}$$

2. Require $\phi(x)$ continuous at $x = 0$:

$$\phi_p + \frac{qN_a}{2\epsilon}x_{po}^2 = \phi_n - \frac{qN_d}{2\epsilon}x_{no}^2$$

Two equations with two unknowns. Solution:

$$x_{no} = \sqrt{\frac{2\epsilon\phi_B N_a}{q(N_a + N_d)N_d}} \quad x_{po} = \sqrt{\frac{2\epsilon\phi_B N_d}{q(N_a + N_d)N_a}}$$

Now problem completely solved.

Other results:

Total width of space charge region:

$$x_{do} = x_{no} + x_{po} = \sqrt{\frac{2\epsilon\phi_B(N_a + N_d)}{qN_aN_d}}$$

Field at metallurgical junction:

$$|E_o| = \sqrt{\frac{2q\phi_B N_a N_d}{\epsilon(N_a + N_d)}}$$


Three cases:

- Symmetric junction: $N_a = N_d \Rightarrow x_{po} = x_{no}$
- Asymmetric junction: $N_a > N_d \Rightarrow x_{po} < x_{no}$
- Strongly asymmetric junction:
i.e. p⁺n junction: $N_a \gg N_d$

$$x_{po} \ll x_{no} \simeq x_{do} \simeq \sqrt{\frac{2\epsilon\phi_B}{qN_d}} \propto \frac{1}{\sqrt{N_d}}$$


$$|E_o| \simeq \sqrt{\frac{2q\phi_B N_d}{\epsilon}} \propto \sqrt{N_d}$$

The lowly-doped side controls the electrostatics of the pn junction.



4. Contact potentials

Potential distribution in thermal equilibrium so far:




Question 1: *If I apply a voltmeter across diode, do I measure ϕ_B ?*

☐ yes ☐ no ☐ it depends

Question 2: *If I short diode terminals, does current flow on outside circuit?*

☐ yes ☐ no ☐ sometimes

We are missing *contact potential* at metal-semiconductor contacts:



Metal-semiconductor contacts: junctions of dissimilar materials

\Rightarrow built-in potentials: ϕ_{mn} , ϕ_{mp}

Potential difference across structure must be zero

\Rightarrow cannot measure ϕ_B !

$$\phi_B = \phi_{mn} + \phi_{mp}$$

Key conclusions

- Electrostatics of pn junction in equilibrium:
 - a *space-charge region*
 - surrounded by two *quasi-neutral regions*
 - ⇒ built-in potential across p-n junction
- To first order, carrier concentrations in space-charge region are much smaller than doping level
 - ⇒ *depletion approximation*.
- Contact potential at metal-semiconductor junctions:
 - ⇒ from contact to contact, there is no potential build-up across pn junction