

# Lecture 17

## The Bipolar Junction Transistor (I)

### Forward Active Regime



### Outline

- The Bipolar Junction Transistor (BJT):
  - structure and basic operation
- I-V characteristics in forward active regime

### Reading Assignment:

Howe and Sodini; Chapter 7, Sections 7.1, 7.2


# 1. BJT: structure and basic operation




**Bipolar Junction Transistor:** excellent for analog and front-end communications applications.

# NPN BJT Collector Characteristics

Similar to test circuit as for an n-channel MOSFET  
...except  $I_B$  is the control variable rather than  $V_{BE}$



## Simplified one-dimensional model of intrinsic device:





**BJT=two neighboring pn junctions back-to-back**


- Close enough for minority carriers to interact
  - $\Rightarrow$  can diffuse quickly through the base
- Far apart enough for depletion regions not to interact
  - $\Rightarrow$  prevent “punchthrough”

## Regions of operation:

$$V_{CE} = V_{BE} - V_{BC}$$



## Basic Operation: forward-active regime




$V_{BE} > 0 \Rightarrow$  injection of electrons from the *Emitter* to the *Base*  
injection of holes from the *Base* to the *Emitter*

$V_{BC} < 0 \Rightarrow$  extraction of electrons from the *Base* to the *Collector*  
extraction of holes from the *Collector* to the *Base*


***Transistor Effect*** : electrons injected from the *Emitter* to the *Base*, extracted by the *Collector*

## Basic Operation: forward-active regime

- Carrier profiles in thermal equilibrium:




- Carrier profiles in forward-active regime:



## Basic Operation: forward-active regime

Dominant current paths in forward active regime:




$I_C$ : electron injection from *Emitter* to *Base* and collection by *Collector*

$I_B$ : hole injection from *Base* to *Emitter*

$I_E$ :  $I_E = -(I_C + I_B)$

# The Flux Picture - Forward Active Region


- The width of the electron flux “stream” is greater than the hole flux stream.
- The **electrons** are supplied by the emitter contact **injected** across the base-emitter SCR and **diffuse** across the base
- Electric field in the base-collector SCR **extracts** electrons into the collector.
- Holes are supplied by the base contact and diffuse across the emitter.
- The reverse injected holes recombine at the emitter ohmic contact.





## 2. I-V characteristics in forward-active regime

*Collector current*: focus on electron diffusion in base



Boundary conditions:

$$n_{pB}(0) = n_{pB0} e^{\left[ \frac{V_{BE}}{V_{th}} \right]}, \quad n_{pB}(W_B) = 0$$


Electron profile:

$$n_{pB}(x) = n_{pB}(0) \left[ 1 - \frac{x}{W_B} \right]$$

## Electron current density:

$$J_{nB} = qD_n \frac{dn_{pB}}{dx} = -qD_n \frac{n_{pB}(0)}{W_B}$$

Collector current scales with area of base-emitter junction  $A_E$ :



Collector terminal current:


$$I_C = -J_{nB} A_E = qA_E \frac{D_n}{W_B} n_{pB0} \cdot e^{\left[ \frac{V_{BE}}{V_{th}} \right]}$$

or

$$I_C = I_S e^{\left[ \frac{V_{BE}}{V_{th}} \right]}$$

$I_S \equiv$  transistor saturation current

**Base current:** focus on hole injection and recombination at emitter contact.



Boundary conditions:

$$p_{nE}(-x_{BE}) = p_{nEo} e^{\left[ \frac{\bar{V}_{BE}}{V_{th}} \right]}, \quad p_{nE}(-W_E - x_{BE}) = p_{nEo}$$

Hole profile:


$$p_{nE}(x) = [p_{nE}(-x_{BE}) - p_{nEo}] \cdot \left( 1 + \frac{x + x_{BE}}{W_E} \right) + p_{nEo}$$

## Hole current density:

$$J_{pE} = -qD_p \frac{dp_{nE}}{dx} = -qD_p \frac{p_{nE}(-x_{BE}) - p_{nEo}}{W_E}$$

Base current scales with area of base-emitter junction

$A_E$ :



Base terminal current:

$$I_B = -J_{pE} A_E = qA_E \frac{D_p}{W_E} p_{nEo} \cdot \left( e^{\left[ \frac{V_{BE}}{V_{th}} \right]} - 1 \right)$$

$$I_B \approx qA_E \frac{D_p}{W_E} p_{nEo} \cdot e^{\left[ \frac{V_{BE}}{V_{th}} \right]}$$

**Emitter current:**  $-(I_B + I_C)$

$$I_E = - \left[ \left( qA_E \frac{D_p}{W_E} p_{nEo} \right) + \left( qA_E \frac{D_n}{W_B} n_{pBo} \right) \right] \cdot e^{\left[ \frac{V_{BE}}{V_{th}} \right]}$$

## Forward Active Region: Current gain

$$\alpha_F = \frac{I_C}{|I_E|} = \frac{1}{1 + \frac{N_{aB} D_p W_B}{N_{dE} D_n W_E}}$$

Want  $\alpha_F$  close to unity---> typically  $\alpha_F = 0.99$

$$I_B = -I_E - I_C = \frac{I_C}{\alpha_F} - I_C = I_C \left( \frac{1 - \alpha_F}{\alpha_F} \right)$$


$$\beta_F = \frac{I_C}{I_B} = \left( \frac{\alpha_F}{1 - \alpha_F} \right)$$

$$\beta_F = \frac{I_C}{I_B} = \frac{n_{pB0} \cdot \frac{D_n}{W_B}}{p_{nE0} \cdot \frac{D_p}{W_E}} = \frac{N_{dE} D_n W_E}{N_{aB} D_p W_B}$$


To maximize  $\beta_F$ :

- $N_{dE} \gg N_{aB}$
- $W_E \gg W_B$
- want npn, rather than pnp design because  $D_n > D_p$

# Plot of $\log I_C$ and $\log I_B$ vs $V_{BE}$




# Common-Emitter Output Characteristics



# What did we learn today?

## Summary of Key Concepts

*npn* BJT in forward active regime:



- **Emitter** “injects” electrons into **Base**, **Collector** “collects” electrons from **Base**
  - $I_C$  controlled by  $V_{BE}$ , independent of  $V_{BC}$
  - (*transistor effect*)

$$I_C \propto e^{\left[ \frac{V_{BE}}{V_{th}} \right]}$$

- **Base**: injects holes into **Emitter**  $\Rightarrow I_B$

$$I_C \propto I_B$$