



MASTERFLUX

Brushless DC Motor Controller Specification

Assembly 025A0044

600A0027 Rev. 3
July 28, 2004

Revision History

Date	Rev	Description	By
10/3/03	1	Preliminary	J. Lawrence
4/7/04	2	Added on/off control through speed pot.	J. Lawerence
7/28/04	3	Added disclaimer	J. Lawrence



WARRANTY INFORMATION

IMPORTANT PRODUCT NOTICE AND WARRANTY INFORMATION

All statements, technical information or data related to Masterflux products are based on information believed to be reliable. However, no representation or warranty, express or implied, is made as to their completeness, accuracy, fitness for a particular purpose or any other matter, including, without limitation, that the practice or application of any such statements, technical information or data is free of patent infringement or other intellectual property misappropriation.

All information provided in this specification is intended for persons having the requisite knowledge, skill, and expertise to properly and completely evaluate such information. Masterflux shall not be responsible or liable for the use, application or implementation of the information provided herein, and all such information is to be used at the risk, and in the sole judgment and discretion, of such persons, their employees, advisors and agents and only after their independent evaluation and determination that the product is suitable for the application intended by such persons.

Masterflux is not in the business of providing technical, engineering or operational information for a fee, and, therefore, any such information is provided as an accommodation and without charge. Masterflux reserves the right to make changes to its products or to discontinue any product at any time without notice, and advises customers to obtain the latest relevant information prior to ordering.

Limited WARRANTY; DISCLAIMER OF WARRANTY; LIMITED REMEDY; LIMITED LIABILITY

All Masterflux products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgement, including, but not limited to, those pertaining to warranty (as stated in its “Warranty to Original Equipment Manufacturers”), patent infringement, and limitation of liability.

MASTERFLUX MAKES NO OTHER WARRANTIES INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE INCLUDING, WITHOUT LIMITATION, ANY WARRANTY THAT MASTERFLUX PRODUCTS ARE SUITABLE OR FIT FOR USE IN ANY HUMAN SAFETY OR LIFE SUPPORT SYSTEMS. If a Masterflux product is found to be defective in materials or workmanship within the warranty period set forth in the “Warranty to Original Equipment Manufacturers,” Masterflux’s sole and exclusive obligation, exercisable in its sole discretion, shall be to repair or replace the product or refund the purchase price of the product as more fully set forth in the “Warranty to Original Equipment Manufacturers.”

Masterflux will not be liable for any loss or damage arising from any Masterflux product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, even if Masterflux shall have been advised of the possibility of such potential loss or damage.



MASTERFLUX

Device Overview

Features

- **Locked rotor detection**
- **Low speed detection**
- **FET thermal shutdown**
- **Motor case thermal shutdown**
- **Under/Over voltage shutdown**
- **Over current shutdown**
- **Up to 25A continuous current**

Description

The 025A0044 Motor Controller has been designed to provide efficient control and monitoring of a DC powered brushless hermetic compressor. The controller will provide a constant speed as specified by the speed setpoint input, independent of motor voltage and load. Fault conditions are monitored continuously. Upon detection of a fault, the motor is shut down. The controller will automatically attempt to restart the motor after the fault condition is cleared. The controller will indicate the fault state by a TTL output. On/Off and speed setpoint are controlled by a 0 to 5 volt analog input. The controller provides a TTL level tachometer output and an analog output proportional to motor current.

Wiring is provided for direct connection to a Masterflux Sierra compressor. The motor wire harness contains three motor phase wires and two wires to connect to the shell temperature switch. Power is supplied through two Anderson PowerPole connectors. Control and indicator signals connect to an eight-pin Molex header. Two fan connectors are available for connecting two 12 volt DC fans.

The motor drive transistors are cooled by a large aluminum finned heatsink. A temperature sensor embedded in the heatsink measures the heatsink temperature. The heatsink provides the mounting points for the assembly with two threaded holes at each end. The heatsink is electrically isolated from the circuitry.

The controller will operate from 0° to 50° C. The circuit board is conformal coated to protect it from corrosion.



Operation

On/Off and Speed Control

Motor on/off and speed setpoint are controlled by a zero to five volt analog input. When the setpoint input voltage rises above one volt the motor will turn on after a 3 second delay. When the setpoint input voltage falls below 0.5 volts the motor turns off. As the setpoint voltage is decreased from 1.0 to 0.5 volts, the minimum speed of 1800 RPM is held. A setpoint input voltage of 1 volt commands the minimum speed of 1800 RPM, five volts commands the maximum speed of 6500 RPM. The motor controller will run the motor at the setpoint speed independent of the load on the motor and the motor voltage provided that the speed is not limited by the motor voltage or maximum current. Five volts and ground are available on the control connector. Connect five volts to one leg of a potentiometer. Connect the other to ground. Connect the wiper of the potentiometer to the speed input for variable speed operation. The input impedance is 10K ohms. A low-pass filter consisting of a 10K ohm resistor and a 10 micro Farad capacitor is used for noise immunity.

Tachometer Output

The motor speed is indicated by a 0 to 5 volt square wave output. The frequency of the square wave is proportional to motor speed at 2.5 RPM/Hz. In the case of a stalled motor, there will be a brief period when the tachometer output is invalid. During a stalled condition, the controller will output a frequency that corresponds with the speed it is trying to achieve even though the motor is not spinning. The controller will quickly detect the stalled condition and shut down.

Motor Current Sense

An analog output is provided on the control connector to indicate motor current. The scaling is 4 Amps/Volt. The output impedance is 10K ohms.

Fault Indicator Output

The controller will signal a fault condition by outputting a logic high value on the fault indicator output. The output is a TTL level signal capable of directly driving an LED. The output can source or sink 25 mA of current. The fault indicator will be active after 10 unsuccessful attempts to restart the motor after a stall is detected, or 10 over temperature conditions of either the heatsink or the shell temperature sensor.

Fault Detection

The motor controller can detect the following faults:

- Locked rotor – if the controller detects a locked rotor it will shut down the motor, delay for 20 seconds and attempt to restart the motor. If the motor does not restart after 10 attempts, the controller will indicate a fault condition by activating the fault indicator output. The controller will continually attempt to restart the motor.



If the controller is successful in restarting the motor, the fault indicator will be deactivated.

- **Low speed** – The compressor must maintain a minimum speed of 1500 RPM for proper lubrication. If the controller detects a low speed condition, it will shut down the motor, delay for 20 seconds and attempt to restart the motor. If the motor does not restart after 10 attempts, the controller will indicate a fault condition by activating the fault indicator output. The controller will continually attempt to restart the motor. If the controller is successful in restarting the motor and maintaining a speed above 1500 RPM for 2 minutes, the fault indicator will be deactivated.
- **Under/Over voltage** – if the motor voltage is outside of the operating limits, the controller will shut down the motor and will delay for 10 seconds. After the delay period, the controller will recheck the voltage conditions. If the voltage is within the operating limits the motor will restart.
- **Heatsink temperature above limit** - if the heatsink temperature rises above 158°F the controller will shut down the motor and delay for 10 seconds. After the delay period the controller will recheck the heatsink temperature. If the temperature has fallen below 158°F the controller will restart the motor. If controller detects ten over temperature faults, the controller will indicate a fault condition by activating the fault indicator. The controller will continue to monitor the heatsink temperature. The controller will restart the motor and deactivate the fault indicator when the heatsink temperature falls below 158°.
- **Compressor Shell temperature above limit** - if the compressor shell temperature switch opens, the controller will shut down the motor and delay for 5 seconds. After the delay period the controller will recheck the compressor shell temperature switch state. If the compressor shell temperature switch is closed the controller will restart the motor. If controller detects ten over temperature faults, the controller will indicate a fault condition by activating the fault indicator. The controller will continue to monitor the switch state. The controller will restart the motor and deactivate the fault indicator when the compressor shell temperature switch is closed.

Engineering Specifications

Absolute Maximum Ratings

Parameter	Min.	Max.	Units
V _M	0	400	V
Speed Setpoint	-0.3	5.05	V
Fault output current sourced		25	mA
Fault output current sunk		25	mA

Note: Do not apply power to controller when controller is not connected to the compressor.



MASTERFLUX

Operating Conditions

Parameter	Min.	Max.	Units
V_M	90	165	V
V_M low voltage shutdown	80	90	V
V_M high voltage shutdown	165	175	V
Temperature Range	0	50	°C

Electrical Characteristics

Parameter	Conditions	Min.	Max.	Units
V _{CC}	I _{OUT} < 50 mA	4.75	5.25	V
+12 V (Fan Connector)	I _{OUT} < 100 mA	10.7	12.7	V
Tachometer				
Output Low Voltage	I _{OL} = 0.4 mA		0.6	V
Output High Voltage	I _{OL} = -0.1 mA	2.2		V
Fault				
Output Low Voltage	I _{OL} = 8.5 mA		0.6	V
Output High Voltage	I _{OL} = -3.0 mA	4.05		V
V _M				
Ripple Current RMS			TBD	A
Current	(Note 1)		25	A
Motor Current Sense				
Source impedance			10K	Ohms
I _{SENSE} Gain		3.8	4.2	A/V
Motor speed	Speed Setpoint = 0 V	1650	1950	RPM
	Speed Setpoint = 5 V	6100	6900	
Note 1: Measured current is steady state. The controller presents a capacitive load to the system. On initial application of power, a substantial in-rush current will result if not limited by external components.				

Testing was done with the 025A0044 controller connected to a model SIERRA00012 compressor.

Connectors

Power

Motor power (V_M) is supplied through the power connector. The power connectors are Anderson Power Products Powerpole 30 Series part number 1330. This connector is self-mating. Connect the positive voltage to the red connector. Connect the return to the black connector.



MASTERFLUX

Control

The control connector, reference designator JP1, is an eight pin shrouded header, Molex part number 70543-0042. The mating connector is Molex part number 50-57-9408.

Pin	Signal Name	Type
1	Motor Current	Output
2	Ground	Output
3	Not connected	
4	Not connected	
5	Tachometer	Output
6	+5 Volts	Output
7	Speed setpoint	Input
8	Fault	Output

Compressor

The three phase wires, reference designators M1, M2, and M3 have AMP Faston connectors, part number 61187-1. The shell temperature switch wires, reference designators JP4, have AMP Faston connectors, part number 2-520128-2.

Pin	Signal Name	Type
Blue	Phase A	Output
Orange	Phase B	Output
Yellow	Phase C	Output
Black	Shell Temperature Switch	Input/Output
Black	Shell Temperature Switch	Input/Output

Fan

Two fan connectors are available, reference designators JP2 and JP3. The connectors are Molex part number 22-23-2021. The mating connector is Molex part number 22-01-2027.

Pin	Signal Name	Type
1	+12 Volts	Output
2	Ground	Output

